



















































































Original		Replacement		Original		Replacement	
	View DVD		Smart		Timer		Shift + AV
	View VCR		Media		F.ADV / Step		Pre Ch
	TV / VCR		TV/R		I<<		I<<
	Input SEL.		AV		Rec		Rec
	Standby / On		Power		Speed		Sleep
	Open / Close		Eject		>>I		>>I
	Info		Info		<<		<<
	1		1		Stop		Stop
	2		2		Play		Play
	3		3		Pause		Pause
	4		4		>>		>>
	5		5		TRK +		Vol +
	6		6		TRK -		Vol -
	7		7		Audio		Dual
	8		8		Prog +		Ch +
	9		9		Prog -		Ch -
	0		0		Menu		Menu





Original	Replacement	Original	Replacement
 Return	 Back		
 Up	 Up		
 Right	 Right		
 Down	 Down		
 Left	 Left		
 OK	 Ok		
 Disc Menu	 D. Menu		
 Clear	 Exit		
 Zoom	 Shift + Eject		
 EZ View	 Options		
 Subtitle	 Subt		
 Angle / IPC	 Format		
 Mode / Repeat	 Text		
 Mark / Search	 Shift + TV/R		

Original	Replacement	Original	Replacement

