






| Original | | Replacement | | Original | | Replacement | |
|---|-------|---|----------------------------|---|----------------|---|-----------------------------|
|  | Power |  | Power |  | Vol- |  | Vol- |
|  | Tv/AV |  | AV / Input / RDS |  | Zoom |  | Zoom / Size |
|  | 1 |  | 1 |  | P- |  | CH- / Page- |
|  | 2 |  | 2 |  | Up |  | Up |
|  | 3 |  | 3 |  | Left |  | Left |
|  | 4 |  | 4 |  | OK/Select |  | OK |
|  | 5 |  | 5 |  | Right |  | Right |
|  | 6 |  | 6 |  | Menu |  | Menu / Home |
|  | 7 |  | 7 |  | Down |  | Down |
|  | 8 |  | 8 |  | Mute |  | Mute / Dimmer |
|  | 9 |  | 9 |  | Red / Picture |  | Red / Netflix / Search |
|  | -/-- |  | Shift + Guide / EPG / -/-- |  | Red / Picture |  | Picture / Format |
|  | 0 |  | 0 |  | Green / Sound |  | Green / APP / Repeat |
|  | Back |  | Back / Return |  | Green / Sound |  | Sound / Title |
|  | Vol+ |  | Vol+ |  | Yellow / Sleep |  | Yellow / YouTube / Repeat |
|  | Scan |  | Smart / List |  | Yellow / Sleep |  | Sleep / Timer |
|  | P+ |  | CH+ / Page+ |  | Blue / Call |  | Blue / Prime Video / Random |





| Original | Replacement |
|--|---|
|  Text |  Text / Goto |
|  Mix |  Shift + Text / |
|  Size |  Shift + Zoom / |
|  Index |  Rec / Rec Mode |
|  Hold |  Stop / Hold |
|  Reveal |  Play / Slow |
|  Subpage |  Subtitle / EQ |
|  Cancel |  Exit / Cancel / Clear |
|  DVB Menu |  D.Menu / Top |
|  i |  Info / Angle |
|  EPG |  Guide / EPG / -/-- |
|  ESC |  Fav / Marker / PC |
|  DVB |  Display / Media |
|  Freeze |  Pause / Step / Freeze |
|  I/II |  Audio / Lang I/II |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

