




































































| Original   | Replacement   |
|--|---|
|  Open / Close |  Eject / Surround          |
|  Power        |  Power                     |
|  V.Mode       |  Picture / Format          |
|  Title        |  Sound / Title             |
|  Subtitle     |  Subtitle / EQ             |
|  Menu         |  Menu / Home               |
|  Repeat       |  Green / APP / Repeat      |
|  A-B RPT      |  Yellow / YouTube / Repeat |
|  Angle        |  Info / Angle              |
|  Audio        |  Audio / Lang I/II         |
|  1           |  1                        |
|  2          |  2                       |
|  3          |  3                       |
|  4          |  4                       |
|  5          |  5                       |
|  6          |  6                       |
|  7          |  7                       |

| Original   | Replacement  |
|--|--|
|  8      |  8                      |
|  9      |  9                      |
|  OSD    |  Display / Media        |
|  N/P    |  Red / Netflix / Search |
|  0      |  0                      |
|  Setup  |  Setup / OPT /          |
|  Up     |  Up                     |
|  Intro  |  OK                     |
|  Left   |  Left                   |
|  Play   |  Play / Slow            |
|  Right |  Right                 |
|  Zoom |  Zoom / Size          |
|  Down |  Down                 |
|  Prog |  TV/Radio /           |
|  CH+  |  CH+ / Page+          |
|  Rec  |  Rec / Rec Mode       |
|  CH-  |  CH- / Page-          |





| Original   | Replacement   |
|--|---|
|  Timer        |  Sleep / Timer               |
|  Quality      |  Blue / Prime Video / Random |
|  Disc         |  D.Menu / Top                |
|  <<           |  << / Tune-                  |
|  >>           |  >> / Tune+                  |
|  I<<          |  I<< / Preset-               |
|  >>I          |  >>I / Preset+               |
|  Pause / Step |  Pause / Step / Freeze       |
|  Stop         |  Stop / Hold                 |
|  <I Slow      |  Shift + Left                |
|  Slow I>     |  Shift + Right              |
|  DVD        |  Shift + 2                 |
|  Mute       |  Mute / Dimmer             |
|  Volume-    |  Vol-                      |
|  Volume+    |  Vol+                      |
|  Source     |  AV / Input / RDS          |
|  Book Mark  |  Fav / Marker / PC         |

| Original  | Replacement  |
|---|--|
|  Edit      |  Text / Goto  |
|  Chap Mark |  Smart / List |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |

