
























	Original	Replacement		Original	Replacement
	Power		Power		I/II
	Input TV		TV/R		Sleep
	Input		AV		Up
	ARC		Media		Down
	*+		Shift + Right		Right
	-*		Shift + Left		Left
	Text		Text		OK
	PIP		3D		Vol+
	Size		Format		Vol-
	Position		Options		Mute
	Red/PIP PR-		Red		PR+
	Green/PIP PR+		Green		PR-
	Yellow/Swap		Yellow		Q.View
	Blue/PIP Input		Blue		1
	Exit		Exit		2
	List		List		3
	Menu		Menu		4





















































	Original	Replacement	Original	Replacement
		5		5
		6		6
		7		7
		8		8
		9		9
		0		0
		FAV		Pre Ch
		Time	 + 	Shift + AV
		Reveal		Subt
		Index		Info













































Original		Replacement		Original		Replacement	
	Power		Power		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	Pause		Pause		7		7
	I<<		I<<		8		8
	<<		<<		9		9
	>>		>>		0		0
	>>I		>>I				
	Menu		Menu				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	OK		Ok				
	1		1				
	2		2				
	3		3				





Original		Replacement		Original		Replacement	
	Power		Power		8		8
	Input		AV		9		9
	Stop		Stop		0		0
	Play		Play				
	Pause		Pause				
	Rec		Rec				
	<<		<<				
	>>		>>				
	PR+		Ch +				
	PR-		Ch -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				

