






































































Original	Replacement	Original	Replacement
 Input/Tuner	 AV / Input / RDS	 Pause/step	 Pause / Step / Freeze
 Power	 Power	 I<< Skip	 I<< / Preset-
 Open/Close	 Eject / Surround	 << Scan	 << / Tune-
 iPod	 Shift + 8	 Scan >>	 >> / Tune+
 PIP	 Zoom / Size	 Skip >>I	 >>I / Preset+
 Display	 Display / Media	 SKP Level	 Setup / OPT /
 Home	 Menu / Home	 Vol+	 Vol+
 Disc Menu	 D.Menu / Top	 Sound	 Sound / Title
 Up/Preset+	 Up	 Mute	 Mute / Dimmer
 Left/Tun.-	 Left	 Vol-	 Vol-
 Enter	 OK	 Night	 TV/Radio /
 Right/Tun.+	 Right	 1	 1
 Down/Preset-	 Down	 2	 2
 Return	 Back / Return	 3	 3
 Title/PopUp	 Shift + Sound / Title	 Marker	 Fav / Marker / PC
 Stop	 Stop / Hold	 4	 4
 Play	 Play / Slow	 5	 5





Original	Replacement
	6
	+ Shift + Red / Netflix /
	7
	8
	9
	+ Shift + Green / APP /
	Subtitle / EQ
	0
	Picture / Format
	Exit / Cancel / Clear
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	+ Shift + Power
	CH+ / Page+
	+ Shift + Vol+

Original	Replacement
	+ Shift + AV / Input / RDS
	CH- / Page-
	+ Shift + Vol-
	Sleep / Timer

