







































































	Original	Replacement	Original	Replacement
	 Power	 Power	 List	 List
	 Input	 AV	 Q.View	 Options
	 D/A/Tv	 Smart	 Menu	 Menu
	 Tv/Radio	 TV/R	 AV Mode	 Back
	 Text	 Text	 Info	 Info
	 I/II	 Dual	 Guide	 Guide
	 Mute	 Mute	 Up	 Up
	 1	 1	 Down	 Down
	 2	 2	 Right	 Right
	 3	 3	 Left	 Left
	 4	 4	 OK	 Ok
	 5	 5	 Vol+	 Vol +
	 6	 6	 Vol-	 Vol -
	 7	 7	 Return/Exit	 Exit
	 8	 8	 FAV	 Pre Ch
	 9	 9	 PR+	 Ch +
	 0	 0	 PR-	 Ch -





Original		Replacement		Original		Replacement	
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Ratio		Format				
	Sleep		Sleep				
	Subtitle		Subt				
	[≡x]/Update		D. Menu				
	[≡i]/Index		Eject				
	[≡o]/Time		Media				
	[≡+]/Hold		Shift + D. Menu				
	[≡?]/Reveal		3D				

