










	Original	Replacement		Original	Replacement
	Power		Power		Auto Power Off
	F		Menu		Blue
	Vol+		Vol +		
	Vol-		Vol -		
	ASC		Smart		
	Mute		Mute		
	Standard		Dual		
	Cinema		TV/R		
	Play		Play		
	Pause		Pause		
	>>I		>>I		
	I<<		I<<		
	DRC On		Red		
	DRC Off		Green		
	Woofer Level+		Ch +		
	Woofer Level-		Ch -		
	Auto Power On		Yellow		

