











Original	Replacement
	Mute
	Power
	TV/Radio
	Guide
	Fav
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Menu
	0 / Swap
	0 / Swap

Original	Replacement
	i
	Vol+
	OK
	CH+
	Up
	Left
	Right
	Vol-
	Down
	CH-
	Exit
	Red
	Green
	Yellow
	Blue
	<< / I<< / Instant Replay
	<< / I<< / Instant Replay



