




































































	Original	Replacement		Original	Replacement
	Power		Power		<< Rev
	Open / Close		Eject		>> Fwd
	Language		Dual		I<< Prev
	Angle		Format		>>I Next
	Subtitle		Subt		Menu
	Prog		Sleep		Title
	1		1		Up
	2		2		Right
	3		3		Down
	4		4		Left
	5		5		Enter
	6		6		Time
	7		7		Setup
	8		8		PBC
	9		9		Shift + Guide
	0/10		0		Vol +
	10+		Guide		Vol -
					Zoom
					Shift + Eject





Original		Replacement		Original		Replacement	
	Return		Back				
	A-B		D. Menu				
	Repeat		Text				
	P-Scan		Media				
	Step		Shift + Pause				
	Slow		Shift + Play				
	N/P		Red				
	L/R		Green				
	Mute		Mute				
	Display		Info				
	Play/Pause		Play				
	Stop		Stop				
	Play/Pause		Pause				
	Default		Smart				

