
































































Original	Replacement	Original	Replacement
 On/Standby	 Power	 <</Tuning-	 <<
 Dimmer	 Subt	 Stop	 Stop
 Clock	 Back	 >>/Tuning+	 >>
 Sleep	 Sleep	 Vol+	 Vol +
 Favorite	 Pre Ch	 Vol-	 Vol -
 Internet Radio	 Media	 Mute	 Mute
 Music Server	 Dual	 CH+	 Ch +
 Online Music	 3D	 CH-	 Ch -
 iPod/USB	 Blue	 DBB/Tone	 List
 M-XPort	 AV	 Menu	 Menu
 Tuner	 Red	 Mode	 D. Menu
 Disc	 Green	 Search	 TV/R
 AUX	 Yellow	 Home	 Smart
 I<<	 I<<	 Up	 Up
 Play	 Play	 Down	 Down
 Pause	 Pause	 Right	 Right
 >>I	 >>I	 Left	 Left





Original		Replacement		Original	Replacement
	Enter/Memo		Ok		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	0		0		
	+10		Guide		
	Clear		Exit		
	Program	 + 	Shift + Sleep		
	X/Random		Format		
	Repeat		Text		
	Display		Info		

