







































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 PC Auto / Open/Close	 Eject	 -/--	 Shift + Guide
 Fav	 Pre Ch	 Recall	 Back
 Fav+	 Shift + Right	 Info	 Info
 Fav-	 Shift + Left	 Input	 AV
 P.Mode	 Shift + Format	 Aspect	 Format
 S.Mode	 Dual	 Up	 Up
 Sleep	 Sleep	 Left	 Left
 1	 1	 OK	 Ok
 2	 2	 Right	 Right
 3	 3	 Down	 Down
 4	 4	 Menu	 Menu
 5	 5	 Mute	 Mute
 6	 6	 Exit / DVD Setup	 Exit
 7	 7	 Exit / DVD Setup	 Options
 8	 8	 Vol+	 Vol +
 9	 9	 Vol-	 Vol -





Original	Replacement	Original	Replacement
 Audio / Lang	 +  Shift + Dual	 >>I	 >>I
 CH+	 Ch +	 Red / Program	 Red
 CH-	 Ch -	 Green / Intro	 Green
 Text / Angle	 Text	 Yellow / Repeat	 Yellow
 Zoom / Hold	 +  Shift + Eject	 Yellow / Repeat	 +  Shift + Text
 TV/Radio /	 TV/R	 Blue / A-B	 Blue
 TV/Radio /	 D. Menu		
 EPG / Title	 Guide		
 Index / D.Disp	 Smart		
 Play/Pause / Size	 Play		
 Play/Pause / Size	 Pause		
 << / Reveal	 <<		
 >> / Subpage / Subtitle	 >>		
 >> / Subpage / Subtitle	 Subt		
 Goto	 Media		
 Stop	 Stop		
 I<<	 I<<		

