






































Original	Replacement
 VHS/DVD Power	 Power
 Direct TV Rec	 Subt
 VHS/DVD	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Cancel / Reset	 Exit
 Input Select	 Guide
 CH+ / Tracking/V-Lock+	 Ch +
 CH- / Tracking/V-Lock-	 Ch -


Original	Replacement
 Create Chapter	 TV/R
 I<< Skip	 I<<
 Skip >>I	 >>I
 REW / << Slow/Search	 <<
 FF / Slow/Search	 >>
 Stop	 Stop
 Pause	 Pause
 Play	 Play
 Direct Navigator / Top Menu	 D. Menu
 Functions	 List
 Up	 Up
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down
 Sub Menu	 Menu
 Return	 Back






Original	Replacement	Original	Replacement
Prog / Check	Sleep		
Display	Info		
Status	Media		
Time Slip	Vol +		
Timer	AV		
Ext Link	3D		
Audio / B	Dual		
Dubbing	Blue		









	Original	Replacement	Original	Replacement
	Power			
	AV			
	Volume+			
	Volume-			
	CH+			
	CH-			





Original		Replacement		Original		Replacement	
	VHS/DVD Power		Power		ShowView		Media
	Direct TV Rec		Subt		I<< Index		I<<
	VHS/DVD		Smart		Index >>I		>>I
	1		1		REW		<<
	2		2		FF		>>
	3		3		Stop		Stop
	4		4		Pause		Pause
	5		5		Play		Play
	6		6		Up		Up
	7		7		Left		Left
	8		8		Enter		Ok
	9		9		Right		Right
	0		0		Down		Down
	Cancel / Reset		Exit		Return		Back
	Input Select		AV		Prog/Check		Sleep
	CH+ / Tracking/V-Lock+		Ch +		Display		Info
	CH- / Tracking/V-Lock-		Ch -		Jet Rew		Shift + <<





	Original	Replacement		Original	Replacement
	Rec				
	Rec Mode				
	Timer				
	A / Ext Link				
	Audio / B				
	Dubbing				

