





































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	Recall		Pre Ch
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Nicam		Options

Original	Replacement	Original	Replacement
	Sleep		Sleep
	Source		AV
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Info		Info
	Media		Media
	Freeze		Smart
	Aspect		3D
	EPG		Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu		Menu





Original	Replacement
Exit	Exit
Text	Text
Play	Play
Pause	Pause
Stop/Hold	Stop
<<	<<
Size	Format
>>/Reveal	>>
I<</Index	I<<
>>I/Subpage	>>I
Lang	Dual
Subtitle	Subt
Rec	Rec
R.List	List
TV/Radio	TV/R
Timeshift	Back
Red	Red

Original	Replacement
Green	Green
Yellow	Yellow
Blue	Blue

