



| Original  |         | Replacement   |       | Original  |             | Replacement   |              |
|---|---------|---|-------|---|-------------|---|--------------|
|    | Power   |    | Power |    | Q.V         |    | Smart        |
|    | Index   |    | Media |    | TV / AV     |    | AV           |
|    | Mute    |    | Mute  |    | V +         |    | Vol +        |
|    | 1       |    | 1     |    | V -         |    | Vol -        |
|    | 2       |    | 2     |    | Up / CH +   |    | Up           |
|    | 3       |    | 3     |    | Down / CH - |    | Down         |
|    | 4       |    | 4     |    | Right / V + |    | Right        |
|    | 5       |    | 5     |    | Left / V -  |    | Left         |
|    | 6       |    | 6     |    | Menu        |    | Menu         |
|    | 7       |    | 7     |    | Menu        |    | Ok           |
|   | 8       |   | 8     |   | Red         |   | Red          |
|  | 9       |  | 9     |  | Green       |  | Green        |
|  | 0       |  | 0     |  | Yellow      |  | Yellow       |
|  | Display |  | Info  |  | Blue        |  | Blue         |
|  | Sleep   |  | Sleep |  | I / II      |  | Dual         |
|  | CH +    |  | Ch +  |  | →ISI←       |  | Shift + Dual |
|  | CH -    |  | Ch -  |  | →IPI←       |  | Format       |



