






Original	Replacement
 Power	 Power
 Setup	 Options
 Mute	 Mute
 Function	 Menu
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Audio	 Dual
 Subtitle	 Subt
 Digest	 Smart

Original	Replacement
 EPG	 Guide
 Info	 Info
 FAV	 Pre Ch
 Red/Photo	 Red
 Green/Music	 Green
 Yellow/Movie	 Yellow
 Blue/Calendar	 Blue
 Zoom	 Eject
 Teletext	 Text
 Tv/Radio	 TV/R
 Recall	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Play/Pause	 Ok



