




























































Original		Replacement		Original		Replacement	
	Power		Power		Exit		Exit
	Mute		Mute		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		Ok		Ok
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		Sound		Shift + Dual
	8		8		Pic		Shift + Format
	9		9		Ch+		Ch +
	0		0		Ch-		Ch -
	Audio		Dual		Sleep		Sleep
	Recall		Back		Aspect		Format
	Tv Menu		Menu		Freeze		Eject
	Source		AV		Tv/Radio		TV/R
	ChList		List		Text		Text





	Original	Replacement		Original	Replacement
	Epg	 GUIDE			I<<
	Fav	 FAV PRE-CH			>>I
	Info	 DISPLAY INFO			Play
	Red	 A			Pause
	Green	 B			Stop
	Yellow	 C			Rec/Rep
	Blue	 D			
	Reveal	 APP MEDIA			
	Hold	 E-MANUAL D.MENU			
	Index	 SHIFT + DISPLAY INFO	Shift + Info		
	Subpage	 SHIFT + TIMER AV	Shift + AV		
	List	 HOME SMART	Smart		
	Mix	 SETTINGS OPT	Options		
	Subtitle	 AD SUBT	Subt		
	Size	 ECO 3D	3D		
	<<		<<		
	>>		>>		

