



Original	Replacement
	Power
	Mute / Dimmer
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Shift + Home / Menu /
	Subtitle / EQ
	D.Menu / Top
	Sleep / Timer
	Setup / OPT /
	Shift + 1
	AV / Input / RDS
	Shift + 0
	Smart / List
	Guide / EPG / -/--
	Fav / Marker / PC

Original	Replacement
	Zoom / Size
	Menu / Home
	Up
	Shift + AV / Input / RDS
	Left
	OK
	Right
	Exit / Cancel / Clear
	Down
	TV/Radio /
	Vol+
	Sound / Title
	CH+ / Page+
	Vol-
	Picture / Format
	CH- / Page-
	1





Original		Replacement	
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	.		Shift + Guide / EPG / -/-
	0		0
	Recall		Back / Return

Original		Replacement	

