



Original	Replacement		
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Last View		Pre Ch
	Radio/Tv		TV/R
	Internet		Smart
	Netflix		Media
	Rec		Rec
	Prog/Check		Sleep

Original	Replacement		
	Play		Play
	>>		>>
	<<		<<
	Pause		Pause
	>>		>>
	I<<		I<<
	Stop		Stop
	Exit		Exit
	i/Status		Info
	Return		Back
	Guide		Guide
	Function Menu		Menu
	Video Menu		D. Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left





Original		Replacement		Original		Replacement	
	OK		Ok		CH+ Tv		Shift + Ch +
	Option		Options		CH- Tv		Shift + Ch -
	Red		Red		Power Tv		Shift + Power
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Audio		Dual				
	Drive Select		List				
	Text		Text				
	STTL		Subt				
	+60s		3D				
	-10s		Format				
	Page/CH+		Ch +				
	Page/CH-		Ch -				
	Tv Vol+		Vol +				
	Tv Vol-		Vol -				
	AV Input Tv		AV				

