



Original	Replacement	Original	Replacement
	Power		Power
	[+]		Info / Angle
	Mute		Mute / Dimmer
	Tv/AV		AV / Input / RDS
	1		1
	2		2
	3		3
	CH+		CH+ / Page+
	4		4
	5		5
	6		6
	CH-		CH- / Page-
	7		7
	8		8
	9		9
	Vol+		Vol+
	C		Back / Return
	0/VCR		0
	-/--		Guide / EPG / -/--
	Vol-		Vol-
	Tv/Text		Text / Goto
	F.P.		Sleep / Timer
	[i]/Index		TV/Radio /
	[+]/Hold		Picture / Format
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Stop		Stop / Hold
	[?]/Reveal		Smart / List
	[o]/Time Text		Display / Media



