







Original	Replacement
 Power	 Power
 Stop	 Stop
 Pause	 Pause
 Rec	 Rec
 <<<	 <<<
 Play	 Play
 >>>	 >>>
 *	 MUTE
 Search	 TV/R
 [<>]	 FORMAT
 TV Guide	 GUIDE
 List	 LIST
 Sources	 AV
 Smart Tv	 MEDIA
 Home	 SMART
 Tv/Exit	 EXIT
 Red	 A

Original	Replacement
 Green	 B
 Yellow	 C
 Blue	 D
 Info	 INFO
 Options	 OPT
 Back	 BACK
 Multiview	 3D
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 OK
 Vol+	 VOL +
 Vol-	 VOL -
 Mute	 MUTE
 CH+	 CH +
 CH-	 CH -



