
























































Original	Replacement
 Power	 Power
 My Choice	 Exit
 Clock	 Shift + AV
 [=]/Smart Tv	 Smart
 Channel Grid	 Dual
 Alarm	 3D
 [□=]/Smart Info	 Shift + Info
 Source	 AV
 [ ]/Tv	 TV/R
 [ <> ]/Format	 Format
 Home	 Shift + Smart
 Play	 Play
 Pause	 Pause
 ≡/Guide	 Guide
 [i]/Info	 Info
 III/Adjust	 Menu
 [-]/Options	 Options

Original	Replacement
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Back	 Back
 CH-	 Ch -
 CH+	 Ch +
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 1	 1
 2	 2





	Original	Replacement		Original	Replacement
	3				
	4				
	5				
	6				
	7				
	8				
	9				
	0				
	Subtitle				
	Text	