






















Original	Replacement
	 Power
	 Text
	 Shift + Sleep
	 Guide
	 Pre Ch
	 Info
	 Vol +
	 Vol -
	 Mute
	 >>
	  <<
	 Stop
	 Play
	 >>
	 <<
	 Smart
	 TV/R

Original	Replacement
	 AV
	 Back
	 Rec
	 Media
	 Sleep
	 Exit
	 Right
	 Left
	 Ch +
	 Ch -
	 Menu






























	Original	Replacement		Original	Replacement
	Power		Power		
	Program		Sleep		
	Tape A/R		Pre Ch		
	Display		Info		
	Vol+		Vol +		
	Vol-		Vol -		
	Title >		>>		
	< Title		<<		
	Stop		Stop		
	Play/Pause		Play		
	Album >>		>>		
	<< Album		<<		





Original	Replacement	Original	Replacement
	Power		Power
	Repeat		Text
	Program		Sleep
	Shuffle		Guide
	Tape A/R		Pre Ch
	Display		Info
	Vol+		Vol +
	Vol-		Vol -
	Title >		>>
	< Title		<<
	Stop		Stop
	Play/Pause		Play
	Album >>		>>
	<< Album		<<

