



| Original | Replacement | Original | Replacement |
|---|----------------|---|-----------------------|
|  | Power |  | Power |
|  | Source |  | AV / Input / RDS |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | TV |  | TV/Radio / |
|  | 0 |  | 0 |
|  | Recall |  | Fav / Marker / PC |
|  | V+ |  | Vol+ |
|  | Mute |  | Mute / Dimmer |
|  | P+ |  | CH+ / Page+ |
|  | V- |  | Vol- |
|  | World/Internet |  | Smart / List |
|  | P- |  | CH- / Page- |
|  | Menu |  | Menu / Home |
|  | Q.Menu |  | D.Menu / Top |
|  | Up |  | Up |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Down |  | Down |
|  | Back |  | Back / Return |
|  | Exit |  | Exit / Cancel / Clear |
|  | i |  | Info / Angle |
|  | Music/Camera |  | Display / Media |
|  | TV Guide |  | Guide / EPG / -/- |
|  | */O |  | Shift + 1 |
|  | */Q |  | Shift + 2 |





| Original | Replacement | Original | Replacement |
|--|---|----------|-------------|
|  [=]/Text |  GOTO TEXT Text / Goto | | |
|  Red |  NETFLIX SEARCH Red / Netflix / Search | | |
|  Green |  APP REPEAT Green / APP / Repeat | | |
|  Yellow |  YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
|  Blue |  Prime Video RANDOM Blue / Prime Video / Random | | |
|  LANG. |  LANG I/II AUDIO Audio / Lang I/II | | |
|  [=].. |  TITLE SOUND Sound / Title | | |
|  [-O-] |  OPT-TOOLS SETUP Setup / OPT / | | |
|  << |  TUNE- << / Tune- | | |
|  |  STEP-FREEZE Pause / Step / Freeze | | |
|  >> |  TUNE+ >> / Tune+ | | |
|  Rec |  REC MODE Rec / Rec Mode | | |
|  ▶ |  SLOW ▶ Play / Slow | | |
|  ■ |  HOLD ■ Stop / Hold | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

