





































































Original	Replacement	Original	Replacement
	Power		Power
	>>>		Red / Menu
	Source		Red / Menu
	I - II		Red / Menu
	Subtitles		Green / Menu
	[i+]		Green / Menu
	[?]		Yellow / Other
	Mix		Yellow / Other
	Zoom		Blue / OK
	Time		Blue / OK
	[PP]		Special Audio
	DNR		Text
	Mosaic		P -
	Up		P +
	Down		Vol -
	Right		Vol +
	Left		1
			2
			3





Original	Replacement	Original	Replacement
	Power		Power
	Time		TV/R
	Zoom		3D
	Mix		Text
	[?]		Shift + Info
	[i+]		Info
	Freeze/Rec		Pause
	Format/Stop		Format
	Source		AV
	I-II		Dual
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Rec		Rec
	<<		<<
	>>		>>
	Stop		Stop
	Play		Play
	Timer		Shift + AV
	P-		Ch -
	P +		Ch +
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/-		Guide

