



Original	Replacement
Power On/Off	Power
Display	Info
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
.	Guide
CH Enter	Pre Ch
P/CH+	Ch +
P/CH-	Ch -
Muting	Mute

Original	Replacement
I-II MTS	Dual
Vol+	Vol +
Vol-	Vol -
Integrator	Smart
Home	Menu
Exit	Exit
Return	Back
Up	Up
Down	Down
Right	Right
Left	Left
Enter/Set	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
PC	Media





Original	Replacement
Input	AV
Ext Input	+  Shift + AV
TV	TV/R
Split	+  Shift + 3D
Sub Input	Subt
Swap	Sleep
(PIP) Shift	3D
Drive Off	+  Shift + Options
Factory	D. Menu
2nd Factory	Text
Set Up/Auto	Options
ID No. SET -	+  Shift + TV/R
Clear +	+  Shift + Exit
Power Control	+  Shift + Power
AV Selection	List
Power Off	+  Shift + Media
Power On	+  Shift + Smart

Original	Replacement
Zoom/Point	Eject
Zoom-	+  Shift + Ch -
Zoom+	+  Shift + Ch +
Freeze	Pause
Size/Screen	Format
Input 1	+  Shift + 1
Input 2	+  Shift + 2
Input 3	+  Shift + 3
Input 4	+  Shift + 4
Input 5	+  Shift + 5
Input 6	+  Shift + 6
Input 7	+  Shift + 7
Input 8	+  Shift + 8





Original	Replacement
Power On/Off	Power
Display	Info
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
CH Enter	Pre Ch
.	Guide
P/CH+	Ch +
P/CH-	Ch -
Muting	Mute

Original	Replacement
I-II MTS	Dual
Vol+	Vol +
Vol-	Vol -
Integrator	Smart
Home	Menu
Exit	Exit
Return	Back
Up	Up
Down	Down
Right	Right
Left	Left
Enter/Set	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
PC	Media





Original	Replacement
Input	AV
Ext Input	Shift + AV
TV	TV/R
Split	Shift + 3D
Sub Input	Subt
Swap	Sleep
(PIP) Shift	3D
Drive Off	Shift + Options
Factory	D. Menu
2nd Factory	Text
Set Up/Auto	Options
ID No.Set -	Shift + TV/R
Clear +	Shift + Exit
Control Power	Shift + Power
AV Selection	List
Power Off	Shift + Media
Power On	Shift + Smart

Original	Replacement
Zoom-	Shift + Ch -
Zoom/Point	Eject
Zoom+	Shift + Ch +
Freeze	Pause
Size/Screen	Format
Input 1	Shift + 1
Input 2	Shift + 2
Input 3	Shift + 3
Input 4	Shift + 4
Input 5	Shift + 5
Input 6	Shift + 6
Input 7	Shift + 7
Input 8	Shift + 8

