



| Original | Replacement |
|--|--|
|  Power |  Power |
|  123 / keypad |  Eject / Surround |
|  Extra |  D.Menu / Top |
|  Up |  Up |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Down |  Down |
|  Return |  Back / Return |
|  Vol Up |  Vol+ |
|  Home / Hub |  Smart / List |
|  CH Up |  CH+ / Page+ |
|  Vol Down |  Vol- |
|  CH Down |  CH- / Page- |
|  Play / Pause |  Shift + Play / |
|  Mute |  Mute / Dimmer |
|  Play |  Play / Slow |

| Original | Replacement |
|---|---|
|  Pause |  Pause / Step / Freeze |
|  Stop |  Stop / Hold |
|  Rec |  Rec / Rec Mode |
|  << / Tune- |  << / Tune- |
|  >> / Tune+ |  >> / Tune+ |
|  I<< / Preset- |  I<< / Preset- |
|  >>I / Preset+ |  >>I / Preset+ |
|  S.Mode |  Sound / Title |
|  AD |  Audio / Lang I/II |
|  AD / Subt. |  Subtitle / EQ |
|  Picture |  Picture / Format |
|  P.Size |  Zoom / Size |
|  Sleep |  Sleep / Timer |
|  Auto Prog |  TV/Radio / |
|  Tools |  Setup / OPT / |
|  TTX/MIX |  Text / Goto |
|  Source |  AV / Input / RDS |





| Original | Replacement | Replacement |
|----------|---|-----------------------------------|
| Menu |  | Menu / Home |
| Info |  | Info / Angle |
| Exit |  | Exit / Cancel / Clear |
| CH List |  | Display / Media |
| 1 |  | 1 |
| 2 |  | 2 |
| 3 |  | 3 |
| 4 |  | 4 |
| 5 |  | 5 |
| 6 |  | 6 |
| 7 |  | 7 |
| 8 |  | 8 |
| 9 |  | 9 |
| Guide |  | Guide / EPG / -/-- |
| 0 |  | 0 |
| Fav CH |  | Fav / Marker / PC |
| Search |  +  | Shift + Yellow / YouTube / Repeat |

| Original | Replacement | Replacement |
|-------------|---|-----------------------------|
| Prime Video |  +  | Shift + Blue / Prime |
| Rakuten Tv |  +  | Shift + Green / APP / |
| Netflix |  +  | Shift + Red / Netflix / |
| Still |  +  | Shift + Pause / Step / |
| Dual I-II |  +  | Shift + Audio / Lang I/II |
| Add / Del |  +  | Shift + Eject / Surround |
| TV / DTV |  +  | Shift + TV/Radio / Program |
| E-Manual |  +  | Shift + OK |
| Media P. |  +  | Shift + Display / Media |
| -/-- |  +  | Shift + Guide / EPG / -/-- |
| PRE-CH |  +  | Shift + Fav / Marker / PC |
| Red |  | Red / Netflix / Search |
| Yellow |  | Yellow / YouTube / Repeat |
| Blue |  | Blue / Prime Video / Random |
| Green |  | Green / APP / Repeat |

