



Original	Replacement
	Power
	Source
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	PRE-CH
	Vol+
	Vol-
	Mute

Original	Replacement
	PR+ / Page+
	PR- / Page-
	CH+ / Page+ CH- / Page- Shift + Smart / List
	Menu / Home
	Smart / List
	Guide / EPG / -/-
	Setup / OPT /
	Info / Angle
	Up
	Down
	Right
	Back / Return
	Left
	OK
	Exit / Cancel / Clear
	Red / Netflix / Search
	Green / APP / Repeat



