





















Original	Replacement	Original	Replacement
 Start/Stop	 Power	 Play	 Play
 Photo	 Options	 Pause	 Pause
 Display	 Info	 Stop	 Stop
 Self Timer	 AV		
 Zero Memory	 Exit		
 Date/Time	 Sleep		
 W	 Ch +		
 T	 Ch -		
 Photo Search	 TV/R		
 A.DUB	 Subt		
 I>/Slow	 List		
 X2	 Dual		
 >>	 >>		
 <<	 <<		
 <  -	 I<<		
 F.ADV	 Format		
   >/+	 >>I		

