








Original	Replacement	Original	Replacement
 Power	 Power	 Tools	 Setup / OPT /
 Mute	 Mute / Dimmer	 vTuner	 Text / Goto
 Play	 Play / Slow	 Menu	 Menu / Home
 Pause	 Pause / Step / Freeze	 Up	 Up
 Stop	 Stop / Hold	 Info	 Info / Angle
 <<	 << / Tune-	 Left	 Left
 >>	 >> / Tune+	 Enter	 OK
 I<<	 I<< / Preset-	 Right	 Right
 >>I	 >>I / Preset+	 Exit	 Exit / Cancel / Clear
 3D Sound	 Sound / Title	 Down	 Down
 Dolby PL II	 Audio / Lang I/II	 Return	 Back / Return
 S/W Level	 Subtitle / EQ	 Vol +	 Vol+
 Eject	 Eject / Surround	 Smart Hub	 Smart / List
 Full Screen	 Zoom / Size	 Tuning / CH +	 CH+ / Page+
 Sleep	 Sleep / Timer	 Vol -	 Vol-
 Function	 TV/Radio /	 DSP	 Display / Media
 Disc Menu	 D.Menu / Top	 Tuning / CH -	 CH- / Page-




























Original	Replacement	Original	Replacement
 1 / RDS Display	 1		Search
 2	 2		Repeat
 3 / TA	 3		
 4 / PTY -	 4		
 5 / PTY Search	 5		
 6 / PTY +	 6		
 7	 7		
 8	 8		
 9	 9		
 SFE Mode	 Guide / EPG / -/--		
 0	 0		
 2D → 3D	 Fav / Marker / PC		
 Red	 Red / Netflix / Search		
 Green / iPod Sync	 Green / APP / Repeat		
 Yellow / Tuner Memory	 Yellow / YouTube / Repeat		
 Blue / Mo/St	 Blue / Prime Video / Random		
 Title Menu / PopUp Menu	 Shift + Menu / Home		

Original	Replacement
	 Shift + Red / Netflix /
	 Shift + Green / APP /





Original	Replacement	Original	Replacement
 Power	 Power	 Stop	 Stop / Hold
 TV Source	 AV / Input / RDS	 Play	 Play / Slow
 Sleep	 Sleep / Timer	 Pause	 Pause / Step / Freeze
 1	 1	 Vol+	 Vol+
 2	 2	 Mute	 Mute / Dimmer
 3	 3	 CH+	 CH+ / Page+
 4	 4	 Vol-	 Vol-
 5	 5	 CH-	 CH- / Page-
 6	 6	 Menu	 Menu / Home
 7	 7	 Tools	 Setup / OPT /
 8	 8	 Up	 Up
 9	 9	 Info	 Info / Angle
 0	 0	 Left	 Left
 I<<	 I<< / Preset-	 Enter	 OK
 >>I	 >>I / Preset+	 Right	 Right
 <<	 << / Tune-	 Return	 Back / Return
 >>	 >> / Tune+	 Down	 Down





Original		Replacement		Original		Replacement	
	Exit		Exit / Cancel / Clear				
	Red		Red / Netflix / Search				
	Green/iPod		Green / APP / Repeat				
	Yellow/Tuner		Yellow / YouTube / Repeat				
	Blue/Mo/St		Blue / Prime Video / Random				
	Smart HUB		Smart / List				
	Search		Shift + Red / Netflix / Search				
	2D-3D		Audio / Lang I/II				

