

































































| Original   | Replacement   | Original   | Replacement  |
|--|---|--|--|
|  Power    |  Power   |  3      |  3      |
|  TV       |  TV/R    |  4      |  4      |
|  →←       |  Smart   |  5      |  5      |
|  Mute     |  Mute    |  6      |  6      |
|  [ .]/[▼] |  Subt    |  7      |  7      |
|  F        |  Menu    |  8      |  8      |
|  O/Timer  |  Info    |  9      |  9      |
|  Up       |  Up      |  0      |  0      |
|  Down     |  Down    |  -/--   |  Guide  |
|  Right    |  Right   |  P-P    |  Pre Ch |
|  Left    |  Left   |  Stop  |  Stop  |
|  P+     |  Ch +  |  <<   |  <<   |
|  P-     |  Ch -  |  Play |  Play |
|  Vol+   |  Vol + |  >>   |  >>   |
|  Vol-   |  Vol - |  |  |
|  1      |  1     |  |  |
|  2      |  2     |  |  |

