































































	Original	Replacement		Original	Replacement
	Standby		Power		Pause
	Info		Info		TV/R
	Mute		Mute		Pre Ch
	P.Mode		Format		AV
	S.Mode		Dual		Back
	Zoom		Shift + Eject		List
	Sleep		Sleep		Up
	1		1		Left
	2		2		Ok
	3		3		Right
	4		4		Down
	5		5		Vol +
	6		6		Vol -
	7		7		Ch +
	8		8		Ch -
	9		9		Menu
	0		0		Guide



Menu



Original	Replacement
 EPG / DVD	 D. Menu
 Audio	 Shift + Dual
 Exit / DVD Setup	 Exit
 Exit / DVD Setup	 Options
 TXT	 Text
 Index / Angle	 Smart
 Size	 3D
 Subtitle	 Subt
 Mix / Open/Close	 Shift + Text
 Mix / Open/Close	 Eject
 Play/Pause /	 Play
 Stop / Hold	 Stop
 A-B / Subpage	 Media
 << / Red	 Red
 << / Red	 <<
 >> / Green	 >>
 >> / Green	 Green

Original	Replacement
 I<< / Yellow	 I<<
 I<< / Yellow	 Yellow
 >>I / Blue	 >>I
 >>I / Blue	 Blue

