







































































Original	Replacement	Original	Replacement
	Power		Power
	PC Auto/Eject		Smart / List
	FAV		Fav / Marker / PC
	FAV-		Shift + CH- /
	FAV+		Shift + CH+ /
	P.Mode		Picture / Format
	S.Mode		Sound / Title
	Sleep		Sleep / Timer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Shift + Guide / EPG / -/--
	0		0
	Back		Back / Return
	Display		Display / Media
	Input		AV / Input / RDS
	Aspect		Shift + Picture / Format
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Menu		Menu / Home
	Mute		Mute / Dimmer
	Exit/DVD Setup		Exit / Cancel / Clear
	Vol+		Vol+
	Lang/Audio		Audio / Lang I/II
	CH+		CH+ / Page+





Original	Replacement
Vol-	Vol-
CH-	CH- / Page-
Angle/Text	Text / Goto
Zoom/Hold	Zoom / Size
D.Menu/Tv/Radi	TV/Radio /
Title/EPG	Guide / EPG / -/--
D.Disp/Index	D.Menu / Top
Play/Size	Play / Slow
Pause/Size	Pause / Step / Freeze
<</Reveal	<< / Tune-
>>	>> / Tune+
Subtitle/Subpage	Subtitle / EQ
Goto	+ Shift + Text /
Stop	Stop / Hold
I<<	I<< / Preset-
>>I	>>I / Preset+
Red/Program	Red / Netflix / Search

Original	Replacement
Green/Intro	Green / APP / Repeat
Yellow/Repeat	Yellow / YouTube / Repeat
Blue/A-B	Blue / Prime Video / Random

