



Original	Replacement
	Mute / Dimmer
	Picture / Format
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	AV / Input / RDS
	0
	Back / Return
	D.Menu / Top
	Fav / Marker / PC

Original	Replacement
	TV/Radio /
	Menu / Home
	Text / Goto
	Up
	Left
	OK
	Right
	Down
	Vol+
	CH+ / Page+
	Vol-
	CH- / Page-
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Info / Angle





Original	Replacement	Original	Replacement
	[?] Smart / List		
	[+] Zoom / Size		
	[◆] Display / Media		
	[≡x] Eject / Surround		
	[:=] Guide / EPG / -/-		
	[] Subtitle / EQ		
	♪ Sound / Title		

