











































































































| Original | Replacement | Original | Replacement |
|--|--|--|--|
|  Power |  Power |  1 |  1 |
|  Open/Close |  Eject |  2 |  2 |
|  FM Mode |  TV/R |  3 |  3 |
|  Tuner Memory |  Format |  4 |  4 |
|  Repeat |  Text |  5 |  5 |
|  Theatre Sync |  Shift + Power |  6 |  6 |
|  Timer Menu |  Smart |  7 |  7 |
|  Sleep |  Sleep |  8 |  8 |
|  Display |  Info |  9 |  9 |
|  Time/Text |  AV |  0 |  0 |
|  Dimmer |  Media |  Clear |  Exit |
|  Function+ |  Ch + |  Folder+ |  Shift + Ch + |
|  Function- |  Ch - |  Folder- |  Shift + Ch - |
|  Picture Navi |  List |  DVD Top Menu |  Menu |
|  Audio |  Dual |  DVD/USB Menu |  D. Menu |
|  Subtitle |  Subt |  EQ |  3D |
|  Angle |  Options |  Return |  Back |





| Original | Replacement | Original | Replacement |
|--|---|---|--|
|  Power |  Power |  Enter |  Ok |
|  Tv/Video |  TV/R | | |
|  1 |  1 | | |
|  2 |  2 | | |
|  3 |  3 | | |
|  4 |  4 | | |
|  5 |  5 | | |
|  6 |  6 | | |
|  7 |  7 | | |
|  8 |  8 | | |
|  9 |  9 | | |
|  10/0 |  0 | | |
|  -/-- |  Guide | | |
|  CH+ |  Ch + | | |
|  CH- |  Ch - | | |
|  Vol+ |  Vol + | | |
|  Vol- |  Vol - | | |

