







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	[]		Smart
	[≡]		Text
	Input		AV
	Output		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide
	C		Pre Ch
	[*]		TV/R
	[↔*]		Subt
	[↑*]		List
	[↑]		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[≡+]		3D
	[+]		Info
	SAT		Back
	Prog+		Ch +
	Prog-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Picture		Format





Original	Replacement	Original	Replacement
	♪		Dual
	←		Left
	Up/+		Up
	Down/-		Down
	Menu		Menu
	OK		Ok
	Power MDP	+	Shift + Power
	>> MDT		>>
	Play MDT		Play
	<< MDT		<<
	Stop MDT		Stop
	Pause MDT		Pause
	Prog+ MDT	+	Shift + Ch +
	Prog- MDT	+	Shift + Ch -



