
































































Original	Replacement
 Power	 Power
 Prog	 TV/Radio /
 Subtitle	 Subtitle / EQ
 Open/Close	 Eject / Surround
 OSD	 Display / Media
 PBC	 D.Menu / Top
 A-B	 Yellow / YouTube / Repeat
 Repeat	 Green / APP / Repeat
 3D	 Shift + Zoom /
 Random	 Blue / Prime Video / Random
 Slow	 Shift + Play /
 Clear	 Exit / Cancel / Clear
 Resume	 Sound / Title
 Digest	 Shift + Subtitle / EQ
 Video	 Shift + 4
 Zoom	 Zoom / Size
 Setup	 Setup / OPT /

Original	Replacement
 Return	 Back / Return
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Angle	 Info / Angle
 Down	 Down
 Language	 Audio / Lang I/II
 N/P	 Picture / Format
 Mute	 Mute / Dimmer
 Vol+	 Vol+
 R/L	 Smart / List
 Title	 Shift + Sound / Title
 Menu	 Menu / Home
 Vol-	 Vol-
 Reset	 Sleep / Timer
 1	 1





Original	Replacement
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0
 10+	 Guide / EPG / -/--
 Goto	 Text / Goto
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze

Original	Replacement
 Stop	 Stop / Hold
 Step	 Shift + Pause / Step /

