

Original	Replacement	Original	Replacement
Power	Power	P+	Ch +
1	1	P-	Ch -
2	2	Home	Smart
3	3	Guide	Guide
4	4	i	Info
5	5	Back	Back
6	6	Exit	Exit
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
Lang	Dual	OK	Ok
TXT	Text	Netflix	Media
Vol+	Vol +	YouTube	Shift + Media
Vol-	Vol -	1☼	Format
Mute	Mute	Prime Video	Shift + Smart
Source	AV	Red	Red





Original		Replacement		Original		Replacement	
	Green	B	Green				
	Yellow	C	Yellow				
	Blue	D	Blue				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec	REC MODE	Rec				
	Play	PLAY MODE	Play				
	Stop		Stop				

