

















































































































Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 More	 Display / Media
 ?	 Guide / EPG / -/--
 Sleep	 Sleep / Timer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Zoom	 Zoom / Size
 0 / AV	 0
 0 / AV	 AV / Input / RDS

Original	Replacement
 OPT	 Setup / OPT /
 SFI	 Picture / Format
 TV / Radio	 TV/Radio /
 Genre	 Smart / List
 Rec	 Rec / Rec Mode
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Red	 Red / Netflix / Search
 Up	 Up
 Blue	 Blue / Prime Video / Random
 Left	 Left
 OK	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Info	 Info / Angle
 <<	 << / Tune-





























































Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 More	 Display / Media
 ?	 Guide / EPG / -/--
 Sleep	 Sleep / Timer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Zoom	 Zoom / Size
 0 / AV	 0
 0 / AV	 AV / Input / RDS

Original	Replacement
 OPT	 Setup / OPT /
 SFI	 Picture / Format
 TV / Radio	 TV/Radio /
 Genre	 Smart / List
 Rec	 Rec / Rec Mode
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Red	 Red / Netflix / Search
 Up	 Up
 Blue	 Blue / Prime Video / Random
 Left	 Left
 OK	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Info	 Info / Angle
 <<	 << / Tune-





Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 More	 Display / Media
 ?	 Guide / EPG / -/--
 Sleep	 Sleep / Timer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Zoom	 Zoom / Size
 0 / AV	 0
 0 / AV	 AV / Input / RDS

Original	Replacement
 OPT	 Setup / OPT /
 SFI	 Picture / Format
 TV / Radio	 TV/Radio /
 Genre	 Smart / List
 Rec	 Rec / Rec Mode
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Red	 Red / Netflix / Search
 Up	 Up
 Blue	 Blue / Prime Video / Random
 Left	 Left
 OK	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Info	 Info / Angle
 <<	 << / Tune-



