







































































Original	Replacement	Original	Replacement
 Power	 Power	 Play	 Play / Slow
 Mute	 Mute / Dimmer	 Pause	 Pause / Step / Freeze
 Sleep	 Sleep / Timer	 >>	 >> / Tune+
 AV	 AV / Input / RDS	 EPG	 Guide / EPG / -/-
 1	 1	 Up	 Up
 2	 2	 Recall	 Fav / Marker / PC
 3	 3	 I<<	 I<< / Preset-
 4	 4	 Left	 Left
 5	 5	 OK	 OK
 6	 6	 Right	 Right
 7	 7	 >>I	 >>I / Preset+
 8	 8	 Zurück	 Back / Return
 9	 9	 Down	 Down
 Rec	 Rec / Rec Mode	 Info	 Info / Angle
 0	 0	 P+	 CH+ / Page+
 Stop	 Stop / Hold	 Exit	 Exit / Cancel / Clear
 <<	 << / Tune-	 Vol+	 Vol+





Original	Replacement	Original	Replacement
	P-		CH- / Page-
	Multimedia		Display / Media
	Vol-		Vol-
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Menü		Menu / Home
	Untertitel		Subtitle / EQ
	Lang.		Audio / Lang I/II
	Ton		TV/Radio /
	Zoom		Zoom / Size
	TXT		Text / Goto
	Internet		Smart / List
	FAV	 + 	Shift + Fav / Marker / PC
	Bildmodus		Picture / Format

