



























Original	Replacement
	
Power	Power
	
Mute	Mute
	
Mosaico	List
	
DVR / Gravações	Media
	
VOD / Videoclube	Smart
	
Pesquisa	Shift + TV/R
	
Exit	Exit
	
Menu	Menu
	
i	Info
	
Vol +	Vol +
	
Vol -	Vol -
	
Up	Up
	
Left	Left
	
OK	Ok
	
Right	Right
	
Down	Down
	
P +	Ch +

Original	Replacement
	
P -	Ch -
	
Stop	Stop
	
<<	<<
	
Pause	Pause
	
Play	Play
	
>>	>>
	
Rec	Rec
	
Red	Red
	
Green	Green
	
Yellow	Yellow
	
Blue	Blue
	
I<<	I<<
	
Back	Back
	
Radio / TXT	TV/R
	
Radio / TXT	Text
	
>>I	>>I
	
1	1





	Original	Replacement		Original	Replacement
	 2	 2			
	 3	 3			
	 4	 4			
	 5	 5			
	 6	 6			
	 7	 7			
	 8	 8			
	 9	 9			
	 0	 0			
	 GUIA /	 Guide			
	 * / AV	 AV			
	 # / -/--	 +  Shift + Guide			

