




























































| Original  | Replacement | Original  | Replacement |
|---|-------------|---|-------------|
|      | Power       |      | Power       |
|      | Open/Close  |      | Eject       |
|      | [ ]X        |      | Smart       |
|      | EQ          |      | Media       |
|      | Mute        |      | Mute        |
|      | →[ ]←       |      | Subt        |
|      | 1           |      | 1           |
|      | 2           |      | 2           |
|      | 3           |      | 3           |
|     | 4           |     | 4           |
|    | 5           |    | 5           |
|    | 6           |    | 6           |
|    | 7           |    | 7           |
|    | 8           |    | 8           |
|    | 9           |    | 9           |
|    | 0           |    | 0           |
|    | +10         |    | Guide       |
|    | [Z]         |    | Format      |
|    | Camera      |    | 3D          |
|    | (Z)))))     |    | Dual        |
|    | Time        |    | AV          |
|    | Prog        |    | Sleep       |
|    | Setup/Mem   |    | Options     |
|    | Title       |    | List        |
|    | Menu/PBC    |    | Menu        |
|    | Return/Exit |    | Back        |
|   | Up          |   | Up          |
|  | Down        |  | Down        |
|  | Right/FAV+  |  | Right       |
|  | Left/FAV-   |  | Left        |
|  | Enter       |  | Ok          |
|  | Function    |  | Pre Ch      |
|  | Tv/Radio    |  | TV/R        |
|  | DVD         |  | D. Menu     |



Source/Auto



| Original  |              | Replacement   |               | Original | Replacement |
|---|--------------|---|---------------|----------|-------------|
|    | Stop         |    | Stop          |          |             |
|    | Play/Pause   |    | Play          |          |             |
|    | Slow         |    | Pause         |          |             |
|    | Info         |    | Info          |          |             |
|    | <</Tuning-   |    | <<            |          |             |
|    | >>/Tuning+   |    | >>            |          |             |
|    | I<</Channel- |    | I<<           |          |             |
|    | >>I/Channel+ |    | >>I           |          |             |
|    | Teletext     |    | Text          |          |             |
|    | EPG          |    | Shift + Guide |          |             |
|   | Vol+         |   | Vol +         |          |             |
|  | Vol-         |  | Vol -         |          |             |
|  | Red/Repeat   |  | Red           |          |             |
|  | Green/A-B    |  | Green         |          |             |
|  | Yellow/Zoom  |  | Yellow        |          |             |
|  | Blue/Clear   |  | Blue          |          |             |

