Mandis shop

# Philips FIDELIO

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| HDMI ARC | HDMI/ARC | 3 | 3 |
| HDMI 1 | HDMI1 | 1 | 1 |
| HDMI 2 | HDMI2 | 2 | 2 |
| OPTICAL | Optical | | Up |
| AUDIO-IN | Audio-In | | Down |
| COAX | Coax | | Right |
| AUX | Aux | | Left |
| Bluetooth | Bluetooth | OK | Ok |
| ON | On | HOME SMART | Smart |
| OFF | Off | APP MEDIA | Media |
| AUDIO SYNC | Audio Sync+ | CH + | Ch + |
| ON AUTO VOLUME | Auto Volume On | DISC NAV LIST | List |
| AUTO VOLUME OFF | Auto Volume | PROG SLEEP | Sleep |
| AUDIO SYNC | Audio Sync- | CH − | Ch - |
| | Vol+ | VOL + | Vol + |
| | Vol- | VOL − | Vol - |

| Original | | Replacement | |
|---|---|---|---|
| | Mute | MUTE | Mute |
| | Treble + | 6 | 6 |
| | Treble- | 4 | 4 |
| | Bass+ | 9 | 9 |
| | Bass- | 7 | 7 |
| V.SURR | V.Surr | 0 | 0 |

https://alle-fernbedienungen.de/en/Philips/1056055-66016-replacement-remote-control-for-Philips-Fidelio-996510062234.html