Original	Replacement
Power	Power
I<<	I<<
Play	Play
Pause	Pause
>>I	>>I
Stop	Stop
Menu	Menu
Mode	Smart
OK	Ok
Album/Preset	Ch +
Album/Preset	Ch -
+	Vol +
-	Vol -
Mute	Mute
Sound	Dual
Info/RDS	Info
Prog	D. Menu

Original	Replacement
Sleep/Timer	Sleep
Clock/Scan	AV

Original	Replacement
Power	Power
I<<	I<<
Play	Play
Pause	Pause
>>I	>>I
Stop	Stop
Menu	Menu
Mode	Smart
OK	Ok
Album/Preset	Ch +
Album/Preset	Ch -
+	Vol +
-	Vol -
Mute	Mute
Sound	Dual
Info/RDS	Info
Prog	D. Menu

Original	Replacement
Sleep/Timer	Sleep
Clock/Scan	AV

Original	Replacement
Power	Power
I<<	I<<
Play	Play
Pause	Pause
>>I	>>I
Stop	Stop
Menu	Menu
Mode	Smart
OK	Ok
Album/Preset	Ch +
Album/Preset	Ch -
+	Vol +
-	Vol -
Mute	Mute
Sound	Dual
Info/RDS	Info
Prog	D. Menu

Original	Replacement
Sleep/Timer	Sleep
Clock/Scan	AV

Original	Replacement
Power	Power
I<<	I<<
Play	Play
Pause	Pause
>>I	>>I
Stop	Stop
Menu	Menu
Mode	Smart
OK	Ok
Album/Preset	Ch +
Album/Preset	Ch -
+	Vol +
-	Vol -
Mute	Mute
Sound	Dual
Info/RDS	Info
Prog	D. Menu

Original	Replacement
Sleep/Timer	Sleep
Clock/Scan	AV