Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Lang		Dual
	TXT		Text
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Source		AV

Original		Replacement	
	P+		Ch +
	P-		Ch -
	Guide		Guide
	Menu		Menu
	i		Info
	Back		Back
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Netflix		Media
	F Play		TV/R
	You Tube		Smart
	Prime Video		Options
	Red		Red

Original		Replacement		Original		Replacement	
	Green	B	Green				
	Yellow	C	Yellow				
	Blue	D	Blue				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec	REC MODE	Rec				
	Play	PLAY MODE	Play				
	Stop		Stop				