Mandis shop

Conceptronic CM3HD

Original	Replacement	Original	Replacement
Power	Power	Vol +	Vol +
View	3D	Vol -	Vol -
Folder	D. Menu	Mute	Mute
Sort	Sleep	Home	Smart
Storage	Rec	Page Up	Ch +
Red/Movie	Red	Page Down	Ch -
Green/Photo	Green	<<	<<
Yellow/Music	Yellow	>>	>>
Blue/File	Blue	I <<	I <<
Aspect	Format	>>I	>>I
Zoom	Eject	Play	Play
Slide	Media	Pause	Pause
Rotate	List	Stop	Stop
Goto	TV/R	Back	Back
Menu	Menu	OSD	Text
Title	Info	Audio	Dual
Exit	Exit	Sub-T	Subt

https://alle-fernbedienungen.de/conceptronic/1649-282-replacement-remote-control-for-conceptronic-CM3HD.htm

Original		Replacement		Original	Replacement
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	Output		AV		
	Setup		Options		