Mandis shop

REMCON1503



Original	Replacement	Original	Replacement
Stop	Stop / Hold		
Play	Play / Slow		
</Prev	<< / Tune-		
>/Next	>> / Tune+		
Volume-	Vol-		
Volume+	Vol+		

https://alle-fernbedienungen.de/en/UNKNOWN/1066105-84922-replacement-remote-control-for-UNKNOWN-REMCON1503.html