Mandis shop

# HOMCOM EF453K-E

| Original | | Replacement | |
|---|---|---|---|
| ON OFF | On/Off | | Power |
| TIMER SET | Timer Set | HOME MENU | Menu / Home |
| ▲ | Up | ▲ | Up |
| DATE TIME | Date Time | PROGRAM TV/ RADIO | TV/Radio / |
| + | + | ◀ | Left |
| OK | OK | OK | OK |
| − | - | ▶ | Right |
| C | C | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| ▼ | Down | ▼ | Down |
| IC | IC | Prime Video RANDOM | Blue / Prime Video / Random |
| TIMER ON/OFF | Timer On/Off | TIMER SLEEP | Sleep / Timer |
| 900W | 900W | TV 1 | 1 |
| COLOR | Color | NETFLIX SEARCH | Red / Netflix / Search |
| 1800W | 1800W | DVD 2 | 2 |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

https://alle-fernbedienungen.de/en/HOMCOM/1066690-96620-replacement-remote-control-for-HOMCOM-EF453K-E.html