Mandis shop

BOSE ROOMMATE

Original	Replacement	Original	Replacement
On / Off	Power	Setup	Setup / OPT /
Mute / Mute All	Mute / Dimmer		
Up	Up		
Left	Left		
OK	OK		
Right	Right		
Down	Down		
I<<	I<< / Preset-		
Volume+	Vol+		
Volume-	Vol-		
>>I	>>I / Preset+		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
Shuffle	Blue / Prime Video / Random		
Repeat	Green / APP / Repeat		
Playlist	Smart / List		

https://alle-fernbedienungen.de/en/BOSE/1062351-93729-replacement-remote-control-for-BOSE-ROOMMATE.html