Mandis shop

LG COV30986701

Original	Replacement
Power	Power
EQ	Subtitle / EQ
Open/Close	Eject / Surround
Preset/Folder+	CH+ / Page+
Preset/Folder-	CH- / Page-
Function	Setup / OPT /
Vol +	Vol +
Vol -	Vol -
Mute	Mute / Dimmer
*	Smart / List
Info	Info / Angle
Program/Memo	TV/Radio /
Rec	Rec / Rec Mode
Menu	Menu / Home
Repeat	Green / APP / Repeat
Up	Up
Down	Down

Original	Replacement
Enter	OK
Right/Tun+	Right
Left/Tun-	Left
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
>>/ >>I	>> / Tune+
<<I / <<	<< / Tune-
RDS	AV / Input / RDS
PTY	Text / Goto

https://alternativeremote.com/LG-COV30986701-replacement-remote-control-for-LG-COV30986701.htm