Mandis shop

Panasonic N2QAYB000984

Original		Replacement	
	Power		Power
CD	Open/Close CD	ZOOM	Eject
►/II	Play/Pause	PLAY MODE	Play
RADIO	Radio	A	Red
	Bluetooth	B	Green
USB/ CD	USB/CD	C	Yellow
DIMMER	Dimmer	HOME SMART	Smart
▶▶/▶▶I	>>/>>I		>>
I◀◀/◀◀	I<</<<		<<
	Stop		Stop
VOL+	Vol+	VOL	Vol +
VOL–	Vol-	VOL	Vol -
SETUP	Setup	SETTINGS OPT	Options
MUTE	Mute	MUTE	Mute
OK	OK	OK	Ok
	Album Up		Up
	Album Down		Down

Original		Replacement	
DISPLAY	Display	DISPLAY INFO	Info
SOUND	Sound	SOUND DUAL	Dual
PLAY MENU	Play Menu	TOP MENU MENU	Menu

https://alle-fernbedienungen.de/en/Panasonic/1063155-24718-replacement-remote-control-for-Panasonic-N2QAYB000984.html